



## HN90

NO	Code	Description	NO	Code	Description
1	HS10704	SCREW 6X38	80	BB40224	SCREW 7X25
2	HN70097	CYLINDER CAP UNIT	81	CN36679	DOOR LATCH
3	HN10773	CYLINDER CAP SEAL	82	KK33353	TORSION SPRING 3353
4	KK23650	COMP SPRING 3650	83	FF41599	PIN 1599 (REPLACES FF41587)
5	HN10774	PISTON STOP	84	HN10796	DOOR
6	HH19719	O-RING 1A2.6X54.5	85	FF41817	STEP PIN 1817
7	HH11157	O-RING ARP568-136 850006	86	HN10797	RATCHET
8	HN10776	HEAD VALVE PISTON	87	KK23912	COMPRESSION SPRING 3912
9	HN10777	HEAD VALVE GUIEDE	88	EE39609	RUBBER WASHER 1.8X6X2
10	HH14729	O-RING AS568-144	89	FF31520	STRAIGHT PIN 1520
11	HH11806	O-RING P27	90	BB40460	BOLT 5 X 28
12	HN70087	MAIN PISTON UNIT	91	HN10790	CONTACT BOLT
13	HN10780	CYLINDER SEAL	92	HH11903	O-RING 1A 1.2 X 4 T29051(REPLACES TA15277)
14	HH19200	O-RING 1A 2.6 X 52.5 <<<<<	93	KK23901	COMPRESSION SPRING 3901
15	HH11109	O-RING 1AP40 <<<<<	94	HN70091	CONTACT ARM B UNIT
16	HN10778	CYLINDER A	95	JJ10404	E-RING 3.2
17	HH19196	O-RING 1A 4.9X43 851439	96	HN10817	CONTACT TIP
18	HN10779	CYLINDER B	97	FF31294	PARALLEL PIN 1294
19	HN10807	BUMPER	98	CN35336	CHECK PAWL
20	HN81061	EXHAUST COVER UNIT	99	KK33337	TORSION SPRING 3337
21	HS10078	FILTER B	100	HN10795	FEED PAWL (USA)
22	HS10077	FILTER A	101	KK23710	COMP. SPRING 3710
23	HN81062	FRAME UNIT	102	KK23788	COMP. SPRING 3788
24	CN34309	PLASTIC SHEET LABEL (100421)	103	FF42216	STEP PIN 2216
25	HN10810	NAME LABEL A	104	HN10808	ARM COVER
26	HN10811	NAME LABEL B	105	CC00401	ELASTIC STOP NUT M5
27	KK23507	SPRING 3507	106	HH11111	O-RING 1AP 14 N5522(REPLACES TA15260)
28	CN35074	TRIGGER LOCK DIAL	107	HN10463	FEED PISTON
29	FF21235	SPRING PIN 3X30	108	HH11107	O-RING AP18
30	HH11120	O-RING ARP568-009 CN65079	109	KK23296	SPRING 3296
31	HN10775	PIPE	110	KK23927	COMPRESSION SPRING 3927
32	HH19127	O-RING A 1.5X5.5	111	CN31570	FEED PISTON STOP
33	HN10379	GRIP COVER	112	HN10464	COMP. SPRING
34	CN35075	TRIGGER LOCK LEVER	113	JJ22407	C-RING 26
35	HN10857	PROTECTOR M	114	CN30602	SPRING HOOK
36	TA17024	FILTER A	115	KK13144	SPRING 3144 (SUPERCEDES KK13040)
37	HH19102	O-RING 1A 2.4X31.8 T29011(REPLACES TA15265)	116	CN30601	SPACER CN65091
38	HN10517	END CAP	117	FF41287	PIN 1287
39	HN10316	END PLUG CAP	118	HN10822	MAGAZINE
40	TT05425	AIR PLUG H-FPM	119	HN10357	CONTACT BUMPER
41	HN10017	PILOT VALVE	120	HN10478	NAIL SUPPORT
42	BB40470	SCREW 5X32	121	CN31963	POST CAP
43	HN10019	TRIGGER VALVE CAP	122	HN10400	ARM GUIDE PIN
44	HN10820	FEED NOZZLE	123	HN10401	CONTACT ARM A
45	HH19722	O-RING A1.5X5	124	HN10853	MAGAZINE CAP
46	HN10043	PILOT CAP	125	HS10118	TRIGGER
47	HN10018	PILOT SEAL	126	HS10117	CONTACT ARM A GUIDE
48	HN12105	O-RING 1A 1.5X12.8	127	HN10851	WARNING LABEL
49	HN10016	TRIGGER VALVE HOUSING	128	HN81072	MAGAZINE CAP ASSY
50	HN10353	TRIGGER VALVE STEM	129	HN81043	MAGAZINE ASSY
51	HH11804	O-RING P6	130	HN10809	DUST COVER
52	HS10139	PILOT VALVE	131	BB40427	T-BOLT 4 X 8(REPLACES TA15544)
53	HH11132	O-RING 1AP10A CN65072	132	EE39172	WASHER 5.1X12X1.2
54	KK23906	COMPRESSION SPRING 3906	133	CN31083	HOOK, DUST COVER
55	KK23619	COMP. SPRING 3619	134	HS10145	SWITCH LEVER A
56	HH19707	O-RING A1.4X2.5	135	HN10067	SCREW 6 X35
57	HS10141	TRIGGER VALVE STEM	145	HN10783	PROTECTOR
58	HH19214	O-RING 1B 1.5X3	146	HN10819	EXHAUST COVER
59	HS10140	TRIGGER VALVE CAP	147	TA81014	STEP PIN KIT
60	HN10100	CONTACT LVER	148	EE39609	RUBBER WASHER 1.8X6X2
61	HS10144	CONTACT LEVER B	149	FF41842	PIN 1842
62	HS10143	CONTACT LEVER A	200	HN81068	ARM GUIDE KIT
63	HS10147	TRIGGER	201	HS80007	TRIGGER VALVE KIT
64	FF22402	SPRING PIN 3X16 (LIGHT LOAD)	202	HN81069	DS KIT
65	HN10786	ARM GUIDE PLATE	203	HN81070	O-RING KIT
66	KK33300	SPRING 3300	204	HN81071	FRAME HANGER KIT
67	HS10146	SWITCH LEVER B			
68	CN34500	SPRING, LEVER			
69	KK23735	COMPRESSION SPRING 3735			
70	KK23736	COMPRESSION SPRING 3736			
71	KK23129	COMPRESSION SPRING 3129			
72	HN10784	ARM GUIDE			
73	HN10785	CONTACT BUMPER			
74	HN10818	CONTACT ARM A			
75	HN10026	ADJUST DIAL			
76	HN10787	ADJUST APACER			
77	HH14734	O-RING AS568-031			
78	HN10794	NOZE			

HN90

79	EE39602	WASHER 7			
----	---------	----------	--	--	--